

VI.3.4B-DELETE PROGRAM FCINIT COMMAND DELETE

Purpose

Command DELETE deletes Rating Curve, Forecast Group, Segment and Rating Curve definitions.

Input Data

First record:

DELETE

Subcommands:

The following subcommands can be input in any order:

<u>First Field (abbreviation)</u>	<u>Subsequent Fields</u>
CGROUPS (CGROUP,CG,C)	Identifiers of Carryover Groups to be deleted
FGROUPS (FGROUP,FG,F)	Identifiers of Forecast Groups to be deleted
RC (R)	Identifiers of Rating Curves to be deleted
SEGMENTS (SEGMENT,SEGS,SEG,S)	Identifiers of Segments to be deleted

Last record:

END None

Example

The following input will delete 1 Carryover Group, 2 Forecast Groups, 3 Segments and 2 Rating Curves:

```
DELETE
  CGROUPS  TEXORADO
  FGROUPS  BRG TEX
  SEGMENTS ROSSE BLASE WIBSE
  RC       ROSSE BLASE
  END
```