

Purpose

MOD BFRATE sets the total baseflow (constant plus variable portions) in Operation BASEFLOW for the specified date.

The area associated with Operation BASEFLOW is used to scale the value entered to be the baseflow for the entire area.

Format

Use Format B3 with two dates on the command card.

```
.BFRATE date validdate [ FGROUP ]  
identifier value [ / opname ]
```

where date is the date for which the data value applies and must be greater than or equal to Technique STARTRUN
validdate is the date after which the MOD is no longer valid and is usually less than or equal to Technique LSTCMPDY
value is the total baseflow in units of flow per area (CFS/MI2 or CMS/KM2)

This MOD is only enabled if the date on the MOD card is less than or equal to validdate or Technique LSTCMPDY. If the date is greater than validdate then the change is made only if validdate is equal to Technique LSTCMPDY.

Example

In this example the total baseflow used in conjunction with event API Operations is changed for several Segments.

```
.BFRATE 1123 1125  
RPDM5 2.5  
RAPM5 4.  
NULM5 2.37  
MNKM5-JDNM5 2.0
```