Ingest_SHEF

1.4;14
Ingest_SHEF



[NOTE: THERE ARE TOKENS IN THE .Apps_defaults HYDRO CONFIGURATION FILES WHICH ALLOW THE USER TO TURN ON/OFF THE LOADING OF 12 TABLES BY THE SHEF DECODER. THE 12 TABLES ARE: IngestFilter, UnkStn, UnkStnValue, ProductLink, TextProduct, LatestObsValue, FcstValue, ObsValue, ObsValueDup, ProcValue, RejectedData, and RiverStatus.]

[NOTE: THE WRITING OF THE ObsValue, ObsValueDup, and FcstValue TABLES BY THE SHEF DECODER HAS BEEN REMOVED FROM THIS DFD TO SIMPLIFY THE DIAGRAM AND BECAUSE THESE TABLES ARE ESSENTIALLY OBSOLETE.]